

ASSEMBLY Programming for MCS-8 + i8086

Dr Jeff Drobman

website → drjeffsoftware.com/classroom.html

email → jeffrey.drobman@csun.edu

i8008 Assembler

MCS-8



Assembly Language

MCS-8

Examples of legal symbols:

```
MAT      START2
MIKE     Z148
TED24    RONA3Z
*
```

Numeric Constants

Two types of numeric constants are recognized by the Assembler: decimal and octal. A decimal number is represented by one to five digits (0-9) within the range of 0 to 16383. An octal number contains from one to five digits (0-7) followed by the letter B. The range of octal numbers is 0 to 37777B.

Copy Data Table

8080/8085

```
; memcpy --
; Copy a block of memory from one location to another.
;
; Entry registers
;     BC - Number of bytes to copy
;     DE - Address of source data block
;     HL - Address of target data block
;
; Return registers
;     BC - Zero

                org     1000h        ;Origin at 1000h
memcpy         public
loop           mov     a,b          ;Test BC,
                ora     c            ;If BC = 0,
                rz                ;Return
                ldax    d            ;Load A from (DE)
                mov     m,a          ;Store A into (HL)
                inx     d            ;Increment DE
                inx     h            ;Increment HL
                dcx     b            ;Decrement BC
                jmp     loop         ;Repeat the loop
                end
```

6800

```
; memcpy --
; Copy a block of memory from one location to another.
;
; Entry parameters
;     cnt - Number of bytes to copy
;     src - Address of source data block
;     dst - Address of target data block

cnt            dw       $0000
src            dw       $0000
dst            dw       $0000

memcpy         public
                ldab    cnt+1        ;Set B = cnt.L
                beq     check        ;If cnt.L=0, goto check
loop           ldx     src           ;Set IX = src
                ldaa    ix           ;Load A from (src)
                inx                ;Set src = src+1
                stx     src
                ldx     dst          ;Set IX = dst
                staa    ix           ;Store A to (dst)
                inx                ;Set dst = dst+1
                stx     dst
                decb                ;Decr B
                bne     loop         ;Repeat the loop
                stab    cnt+1        ;Set cnt.L = 0
check          tst     cnt+0         ;If cnt.H=0,
                beq     done         ;Then quit
                dec     cnt+0        ;Decr cnt.H
                decb                ;Decr B
                bra     loop         ;Repeat the loop
done           rts                  ;Return
```


i8080 Code: RAM Test

COMP122

1972

MCS-8

```
*1101 RAM TEST
*PROGRAM: A0802
*DATE: MAY 8, 1972
*PROGRAMMER: DR. PHIL TAI, MCS, INTEL CORP.
*
*
*
```

Header

```
BEGIN  ORG 0
        LAI 0
        OUT 10B
        OUT 11B
        OUT 12B
        OUT 13B
        LBI 8
        LCI 0
        LHI 8
        LLI 0
        XRA
        LMA
        INL
        CPL
        JFZ LM2
        INH
        LAI 12
        CPH
        JFZ LM1
        LHI 8
REPT4   LAB
        OUT 10B

        LOAD 0 TO AC
        WRITE TO OUTPUT 0
        WRITE TO OUTPUT 1
        WRITE TO OUTPUT 2
        WRITE TO OUTPUT 3
        LOAD 8 TO REG. B
        LOAD 0 TO REG. C
        LOAD 8 TO REG. H
        LOAD 0 TO REG. L
        CLEAR AC
        LOAD AC TO MEMORY
        L = L + 1
        AC = L
        JUMP IF AC IS NOT ZERO
        H = H + 1
        LOAD 12 TO AC
        AC = H
        JUMP IF AC IS NOT ZERO
        LOAD REG. B TO AC
```

ORG 0

XRA

INL

INH

OUT

```
REPT3   LLC
        LAC
        OUT 13B
        LAI 255
        LMA
        CPM
        JFZ ERROR
REPT2   LAH
        OUT 10B
REPT5   XRA
        INL
        CPL
        JNZ REPT1
        LAL
        OUT 11B
        XRA
        CPM
        JFZ ERROR
        JMP REPT5

        LOAD REG. C TO L
        LOAD REG. C TO AC
        LOAD 255 TO AC
        LOAD AC TO MEMORY
        AC = M
        JUMP IF AC IS NOT ZERO
        LOAD REG. H TO AC
        CLEAR AC
        L = L + 1
        AC = L
        JUMP IF AC = 0
        LOAD REG. L TO AC
        CLEAR AC
        AC = M
        JUMP IF AC IS NOT ZERO
```


Sample Flowchart

Search for a Char

MCS-8




Figure 21. Subroutine to Search For Period

Sample Code

Search for a Char

MCS-8

PROGRAMMING EXAMPLES

Sample Program to Search A String Of Characters In Memory Locations 200-219 For A Period (.)

MNEMONIC	OPERAND	EXPLANATION	BYTES	LOCATION	ROM CODE	COMMENT
Start: LLI	200	Load L with 200	2	100	00110110	
				101	11001000	(200)
LHI	0	Load H with 0	2	102	00101110	
				103	00000000	(0)
Loop: LAM		Fetch Character from Memory	1	104	11000111	ASC II
CPI	"."	Compare it with period	2	105	00111100	ASC II
				106	00101110	(.)
JTZ	Found	If equal go to return	3	107	01101000	
				108	01110111	
				109	00000000	(119)
CAL	INCR	Call increment H&L subroutine	3	110	01000110	
				111	00111100	
				112	00000000	(60)
LAL		Load L to A	1	113	11000110	
CPI	220	Compare it with 220	2	114	00111100	
				115	11011100	(220)
JFZ	Loop	If unequal go to loop	3	116	01001000	
				117	01101000	
				118	00000000	(104)
Found: RET		Return	1	119	00000111	
INCR: INL		Increment L	1	60	00110000	
RFZ		Return if not zero	1	61	00001011	
INH		Increment H	1	62	00101000	
RET		Return	1	63	00000111	

Interrupts

MCS-8




Figure 5. 8008 Interrupt

Computer Architecture

x86 Assembly Language

i8086 Code



John Stephenson, Analyst programmer
magnetic tape reels.

Answered 9h ago

Set low byte A = all 1's or all 0's

Several methods:

1	MOV	AL, FF
2		
3		
4	OR	AL, FF
5		
6		
7	XOR	AL, AL
8	NOT	AL



MOV

AH

AL

AX

UPPER CASE!

i8086 Code

Subroutine to Sum Array Elements

Save

Loop

Restore

```

1  ADD_N_NUMBERS_FROM_ARRAY: // we suppose CX will hold how many
   we want
2  PUSH SI                  // may not be needed, saves si value
3  PUSH BX                  // may not be needed, saves BX value
4  LEA SI, MYDATA           // we move the memory address to SI
5  CLD                     // clean the direction flag so goes forward.
6  XOR BX,BX                ← BX = 0 // clean the AX (make it zero)
7  ANFR1
8  LODSW                   // copies each data to AX
9  ADD BX,AX                ← // makes BX += AX (so holds the total sum)
10 LOOP ANFR1              // goes to the upper loop until CX = 0
11 MOV AX,BX
12 POP BX                  // restores bx
13 POP SI                  // restores si, (each of this required if the
   push was done)
14 RET

```

AX

AH	AL
----	----

BH	BL
----	----

BX

i8086 Code

Subroutine to Sum Array Elements

should be called like this.

CALL sub

Load Im

```
1 → MOV CX,10    //where 10 is in decimal format and its absolute
    value (in some compilers requires #)
2  CALL ADD_N_NUMBERS_FROM_ARRAY
```

to do it from just 10 different constant values have no much sense (yu can do manually the sum) but will be

```
1  XOR AX,AX
2  ADD AX,VAL1
3  ADD AX,VAL2
4  ADD AX,VAL3
5  ADD AX,VAL4
6  ADD AX,VAL5
7  ADD AX,VAL6
8  ADD AX,VAL7
9  ADD AX,VAL8
10 ADD AX,VAL9
11 ADD AX,VAL10
```

Loop unrolling

x86 Assembly

x86 assembly language

From Wikipedia, the free encyclopedia

x86 Assembly Language is a family of [backward-compatible assembly languages](#), which provide some level of compatibility all the way back to the [Intel 8008](#) introduced in April 1972. x86 [assembly languages](#) are used to produce object code for the [x86](#) class of processors. Like all assembly languages, it uses short [mnemonics](#) to represent the fundamental instructions that the [CPU](#) in a computer can understand and follow. [Compilers](#) sometimes produce assembly code as an intermediate step when translating a high level program into [machine code](#). Regarded as a [programming language](#), assembly coding is *machine-specific* and *low level*. Assembly languages are more typically used for detailed and time critical applications such as small [real-time embedded systems](#) or [operating system kernels](#) and [device drivers](#).

Using the flags register [[ec](#)

Flags are heavily used for comparis
conditional jump instructions can be

```
    cmp eax, ebx
    jne do_something
    ; ...
do_something:
    ; do something here
```

x86 Assembly

DOS

"Hello world!" program for DOS in MASM style assembly [ed

Using interrupt 21h for output – other samples use [libc](#)'s printf to print to [stdout](#).¹

```
.model small
.stack 100h

.data
msg db 'Hello world!$'

.code
start:
    mov ah, 09h    ; Display the message
    lea dx, msg
    int 21h
    mov ax, 4C00h  ; Terminate the executable
    int 21h

end start
```


x86 Assembly

COMP122

Windows

"Hello world!" program for Windows in NASM style assembly

```
; Image base = 0x00400000
%define RVA(x) (x-0x00400000)
section .text
push dword hello
call dword [printf]
push byte +0
call dword [exit]
ret

section .data
hello db "Hello world!"

section .idata
dd RVA(msvcrt_LookupTable)
dd -1
dd 0
dd RVA(msvcrt_string)
dd RVA(msvcrt_imports)
times 5 dd 0 ; ends the descriptor table
```

```
msvcrt_string dd "msvcrt.dll", 0
msvcrt_LookupTable:
dd RVA(msvcrt_printf)
dd RVA(msvcrt_exit)
dd 0
```

```
msvcrt_imports:
printf dd RVA(msvcrt_printf)
exit dd RVA(msvcrt_exit)
dd 0
```

```
msvcrt_printf:
dw 1
dw "printf", 0
msvcrt_exit:
dw 2
dw "exit", 0
```

printf

x86 Assembly

COMP122

```

; _memcpy(dst, src, len)
; Copy a block of memory from one location to another.
;
; Entry stack parameters
;     [BP+6] = len, Number of bytes to copy
;     [BP+4] = src, Address of source data block
;     [BP+2] = dst, Address of target data block
;
; Return registers
;     AX = Zero

0000:1000                org     1000h        ; Start at 0000:1000h

0000:1000                _memcpy proc
0000:1000 55             push     bp          ; Set up the call frame
0000:1001 89 E5          mov      bp,sp
0000:1003 06             push     es          ; Save ES
0000:1004 8B 4E 06       mov      cx,[bp+6]    ; Set CX = len
0000:1007 E3 11         jcxz     done        ; If len = 0, return
0000:1009 8B 76 04       mov      si,[bp+4]    ; Set SI = src
0000:100C 8B 7E 02       mov      di,[bp+2]    ; Set DI = dst
0000:100F 1E             push     ds          ; Set ES = DS
0000:1010 07             pop      es

0000:1011 8A 04         loop    mov     al,[si]    ; Load AL from [src]
0000:1013 88 05         loop    mov     [di],al    ; Store AL to [dst]
0000:1015 46             loop    inc     si        ; Increment src
0000:1016 47             loop    inc     di        ; Increment dst
0000:1017 49             loop    dec     cx        ; Decrement len
0000:1018 75 F7         loop    jnz     loop      ; Repeat the loop

0000:101A 07         done    pop     es          ; Restore ES
0000:101B 5D         done    pop     bp          ; Restore previous call frame
0000:101C 29 C0         done    sub     ax,ax      ; Set AX = 0
0000:101E C3         done    ret              ; Return
0000:101F                end proc

```

x86 Assembly

The above routine is a rather cumbersome way to copy blocks of data. The 8086 provides dedicated instructions for copying strings of bytes. These instructions assume that the source data is stored at DS:SI, the destination data is stored at ES:DI, and that the number of elements to copy is stored in CX. The above routine requires the source and the destination block to be in the same segment, therefore DS is copied to ES. The loop section of the above can be replaced by:

0000:1011 FC		<code>cld</code>	<i>; Copy towards higher addresses</i>
0000:1012 F2	<code>loop</code>	<code>repnz</code>	<i>; Repeat until CX = 0</i>
0000:1013 A4		<code>movsb</code>	<i>; Move the data block</i>